



**8510**


Manuale utente .....	3
User manual .....	4
Gebrauchsanleitung .....	5
Notice d'utilisation.....	6
Gebruikershandleiding .....	7
Manual usuario.....	8



**Vodafone  
Automotive**

# 8510

- CHIAVE ELETTRONICA
- ELECTRONIC KEY
- ELEKTRONISCHER SCHLÜSSEL
- CLE ELECTRONIQUE
- ELEKTRONISCHE SLEUTEL
- LLAVE ELECTRONICA



- PANNELLO DI CONTROLLO
- ELECTRONIC KEY PLUG
- ELEKTRONISCHE SCHALTAFEL
- PANNEAU DE CONTROLE
- CONTROLEPANEEL
- TABLERO DE CONTROL



## PRODUCT DESCRIPTION

Passive arming immobiliser, controlled by antiscanner electronic key.

## ARMING THE SYSTEM

When the immobiliser will automatically arm itself after 60 s the ignition has been turned off:

- The engine cut will be activated
- The LED will blinking

## DISARMING THE SYSTEM

When inserting the electronic key into the control panel mounted under the dash:

- reset of the engine's functions
- extinction of the LED

After 60 s by the disconnection if the check control has not restarted, the immobiliser will insert again.

## USER NOTES

- 1) The electronic key is the only means to disarm the system.**
- 2) A built in safety circuit ensure that immobiliser can not be armed while the vehicle's engine is running.
- 3) As the electronic key do not require battery and maintenance they are completely sealed.
- 4) For any failure of the system, or in case of loss of one of the key, contact your installer.